



- Note:
1. Set MCU in the reset status and then confirm that all SPI's pins are HIZ. Recommend series resistors are greater than 300 ohm and pull-up resistors are 4.7K ohm.
 2. Connect all pins of the SPI flash to the LABTOOL-S100 else VCC pin if power supply from the board.
 3. Disable instertion test function
 4. Programming SPI flash